Xerox Phaser 8870 Configuration Guide

UF Health – Xerox Private Data



Document Revision History

By	Date	Version Number	Description of changes
Allen Messick	02-03-2014	1.0	initial
Allen Messick	02-11-2014	1.1	

Page 2 of 17 Xerox / UF Health 3rd Party Private Data Version 1.1

Phaser 8870 CetnreWare Information Services

Before you begin:

- Locate your printer IP address using the Configuration Report or the Machine Control Panel.
 - 1. At your computer, open a Web browser, type the IP address of the printer in the address field, then press **Enter** or **Return**.

Disable TFTP

- 1. Click the **Properties** button.
- 2. Select **Protocols > TFTP.**
- 3. Click the TFTP pulldown and select Off.
- 4. Click Save Changes.



Page 3 of 17 Xerox / UF Health 3rd Party Private Data Version 1.1

Disable FTP

- 1. Click the **Properties** button.
- 2. Select **Protocols** > **FTP**.
- 3. Click the FTP pulldown and select **Off**.
- 4. Click Save Changes.

Internet Services Phaser 8860	Q Printer Neighborho	Index Help
Status Jobs Name: Phaser 8860 DNS: Unknown IPv4: 13.226.178.15 IPv6: Disabled Properties Phaser 8860 - About Printer General - E-Supplies - Mail Alerts - Interfaces Protocols - TCP/IP - SLP - UPnP - IFIP - Port 9100 - IPP - SNMP	Print Properties FTP Settings You can retrieve job accounting r printer using the FTP protocol. FTP Login Password Page Description Language Filtering Save Changes	records and send print-ready files to the
Email Server		

Page 4 of 17 Xerox / UF Health 3rd Party Private Data Version 1.1

Disable EtherTalk

- 1. Click the **Properties** button.
- 2. Select **Protocols > EtherTalk.**
- 3. Click EtherTalk pulldown and select Off.
- 4. Click Save Changes.



Page 5 of 17 Xerox / UF Health 3rd Party Private Data Version 1.1

Note: The remainder of the SNMPv3 Configuration will be completed at Install.

Enable SNMP v3

- 1. Click the **Properties** button.
- 2. Select **Protocols** > **SNMP**.
- 3. Click **Configure SNMP v3** button.

Internet Services Phaser 8860	Printer Neighborhood	Index Help
StatusJobsName: Phaser 8860DNS: UnknownIPv4: 13.226.178.15IPv6: Disabled	Print Properties SNMP Configuration Current State: SNMP v1/v2c Enabled	Support
Properties Phaser 8860 About Printer General E-Supplies	SNMP Properties SNMP v1/v2c Protocol: SNMP v3 Protocol: SNMP Enable/Disable:	Configure SNMP v1/v2c Configure SNMP v3 Disable SNMP Now
Mail Alerts Interfaces Protocols Implies	SNMP Access Control List Host Access List:	
- UPnP - TETP - Port 9100 - LPR - IPP - SINNE - FTP - Email Server - Remote Printing	Save Changes	Discard Changes

4. Click Configure Accounts button.



Page 7 of 17 Xerox / UF Health 3rd Party Private Data Version 1.1

- 5. Change the User Name to Xadmin.
- 6. Enter the SNMP password in all four of the password boxes.
- 7. Change the Authentication Protocol to MD5 and the Privacy Protocol to CBC-DES.
- 8. Click Create.



9. Click the **Next** button.

Page 8 of 17 Xerox / UF Health 3rd Party Private Data Version 1.1



10. Click the **Next** button.

Page 9 of 17 Xerox / UF Health 3rd Party Private Data Version 1.1

Name: Phaser 8860 DNS: Unknown IPV4: 13.226.178.15 IPV6: Disabled		Configure SN	MP v3:	Key User Account
Properties Phaser 8860 About Printer General CE-Supplies Protocols Protocols CEP		Key User Account User Name: Authentication Protocol Authentication Password: Confirm Password: Privacy Protocol: Privacy Password: Confirm Password: MIB Access:	rd: Create	keyuser SHA1 CFB-AES-128 © Read/Write • Read ✓ Hide Typing
SNUT FTP Email Server Remote Printin EtherTalk WSD III	a +	Note:Setting the key u Use Hex For Authentica	ation/Privacy P Back Next	optional. asswords > Cancel

11. Click the **Finish** button.



12. Click the **Cancel** button.



13. **SNMP v3** is now Enabled.

Internet Services Phaser 8860	Printer Neighborhood	Index Help
Status Jobs	Print Properties	Support
Name: Phaser 8860 DNS: Unknown IPv4: 13.226.178.15 IPv6: Disabled	SNMP Configuration Current State: SNMP v3 Enabled	
Properties	SNMP Properties	
Phaser 8860 About Printer General C E-Supplies	SNMP v3 Protocol: SNMP Enable/Disable:	Configure SNMP v1/v2c Configure SNMP v3 Disable SNMP Now
Mail Alerts		
Protocols	SNMP Access Control List Host Access List:	
SLP SLP UPnP UPnP Drt 9100 DLPR DIP SNNE FIP Email Server Remote Printing	Save Changes	Discard Changes

Page 13 of 17 Xerox / UF Health 3rd Party Private Data Version 1.1

Enable HTTPS

- 1. If you are at the Home screen click the **Properties** button.
- 2. Select **Security > HTTPS.**
- 3. In the Use SSL box click the pulldown and select To Secure Pages and Passwords.
- 4. Click Save Changes.

Internet Services Phaser 8860	,	Printer leighborhood	E Index	? Help
Status Jobs	Print	Properties	Support	
Name: Phaser 8860 DNS: Unknown IPv4: 13.226.178.15 IPv6: Disabled	HTTPS			
Descention	Configure HTTPS			
Apparent 9960	Use SSL :	To Secure Pages an	d Passwords 🔻 🧲	
About Printer General General CE-Supplies Mail Alerts Dinterfaces Frotocols Fundations Web Server EMPROTECTS CONTACT Security CAdministrative Security CONTACT	Friendly Name	es	Installed 9/26/2013 1 - 1 of 1 Discard Changes	

Disable USB Port

- 1. If you are at the Home screen click the **Properties** button.
- 2. Select Interfaces.
- 3. Select the pulldown next to USB Port and select Off.
- 4. Click Save Changes.

Internet Services Phaser 8860	Printer Neighborhood	Index Help
Status Jobs	Print Properties Interfaces	Support
Properties Phaser 8860 Description Phaser 8860 Description Phas	USB Port Settings USB Port USB Port Timeout Page Description Language	Off • 30 seconds AutoSelect •
Mail Alerts Mai	Ethernet Interface Settings Speed Actual Speed Machine Address Connector	Automatic 100Base-TX full duplex 00:00:aa:a9:27:1c RJ45
L Clone Printer	Save Changes	Discard Changes

Page 15 of 17 Xerox / UF Health 3rd Party Private Data Version 1.1

Set Admin Password

- 1. If you are at the Home screen click the **Properties** button.
- 2. Select **Security > Administrative Security**.
- 3. In the User Name box type admin.
- 4. In the **Password** and **Verify Password** boxes type the new password.

<u>Name</u> : Phaser 8860 <u>DNS</u> : Unknown <u>IPv4</u> : 13.226.178.15 <u>IPv6</u> : Disabled	Administrative Securit To prevent unauthorized changes to printer password and/or host list in the Administrat	y Settin settings, enter or Settings area	gs a userna a. After c	ime and configuring
Properties	Administrator Settings, you can change the Authorization Settings.	Key User Settir	ngs and t	he Feature
- About Printer	Administrator Settings			
General	Host Access List User Name	Unrestri	cted	_
	Password Verify Password			
∎© Emulations ∎© Web Server ≣	Key User Settings			
Administrative Se	Host Access List	Unrestricted		-
- Printing Security Se	User Name		201202	
- <u>Certificates</u>	Password			
- 1 802.1X - 1 HTTPS	Verify Password	[
Control Panel Locko	Feature Authorization			
Clone Printer		<u>Admin</u>	<u>Key</u> User	Any User
< <u>Ⅲ</u> ►	Administration			
	Modify Configuration Web Pages	~		V
	View Configuration Web Pages	~	V	V
	View Home & Status Web Dages	а г	-	Land Land

Page 16 of 17 Xerox / UF Health 3rd Party Private Data Version 1.1

- 5. In the **Feature Authorization** are of the web page clear all the checkboxes.
- 6. Click Save Changes.

